

ERSATZTEILLISTE

ML 390FB

ZEICHNUNG 1 - PRINTER UNIT (1/4)




LISTE 1 - PRINTER UNIT (1/4)

NR.	BEZEICHNUNG	BESTELL-NR.
1	PRINT HEAD	4YA4023-2011G1
5	SHPZ PCB (MAIN PCB W/O ROM)	4YA4053-2290G102
6	OPERATOR PANEL ASSY	3YX4053-2017G2
	OPERATOR PANEL SHEET (FOIL)	3PB4053-2018P1
	OPERATOR PANEL FRAME (PLASTIC FRAME)}	2PP4053-2019P001
	SHPO PCB (PCB ONLY)	4YA4053-2291G1
8	CIRCUIT PLATE	1PP4053-2015P1
12	CONNECTOR CORD (SHPX PCB-OPERATION PANEL)	4YS4011-4367P2
13	CONNECTOR CORD (SHPX PCB, POWER SUPPLY BOARD)	4YS4011-4311P2
15	ICCK PCB	4YA4053-2299G1
24	PLATEN KNOB	3PP4025-2871P1
39	LOWER COVER	3PA4053-2417G1
40	UPPER COVER	2PP4053-2006G1
41	ACCESS COVER	3PP4053-2007G8
42	GEAR COVER	4PP4053-1445P7
43	SHEET STACKER	3PA4053-2056G1
52	AC CABLE 230V	3YS4011-1265P1
	AC CABLE 240V	3YS4011-1192P1
53	TRANSFORMER	4YB4056-8472P2
54	FILTER ASSEMBLY	4YX4056-3477G2
55	POWER SUPPLY BOARD	3YU5057-3311G1
56	FUSE (PRIMARY SIDE 250V)	FP-21108-2
57	FUSE (SECONDARY SIDE 250V)	FP-21107-2
58	CIRCUIT BOARD	4PP4053-2021P1
59	BRACKET (A)	4PP4053-2155P1
60	CARD COVER	2PP4053-2051P7

ZEICHNUNG 2 - PRINTER UNIT (2/4)


LISTE 2 - PRINTER UNIT (2/4)



NR.	BEZEICHNUNG	BESTELL-NR.
4	SPACERACK	4PP4053-2258P1
9	TRACTOR ASSY (R)	4PA4025-2636G1
10	TRACTOR ASSY (L)	4PA4025-2642G1
16	ADJUSTMENT BUSHINGS (L)	4PP4053-2204P1
17	ADJUSTMENT BUSHINGS (R)	4PP4053-2205P1
18	ADJUSTMENT LEVER	3PP4053-2014P2
19	CHANGE ARM C	4PP4053-2208P1
20	CHANGE LEVER	3PP4053-1397P4
21	CHANGE ARM B	4PP4053-1978P1
22	STAGE ASSEMBLY	3PP4053-2259G1
23	STAGE LOCK STAY	4PP4053-1410P1
38	SHEET GUIDE	4PP4025-2643P1
44	HEAD CABLE	2PU4007-1170P1
61	CHANGE LEVER SHAFT	4PP4053-1979P1
62	LOCK SHAFT	4PB4053-2295P1
63	TRACTOR SHAFT	4PP4053-1390P2
64	GUIDE PLATE	4PP4053-1383P1
65	CARRIAGE SHAFT	4PB4053-2201P1
66	GUIDE BUSH	4PP4044-1304P1
67	DRIVEN GEAR	4PP4044-1550P1
68	CABLE GUIDE	4PP4053-2273P1
79	TENSION SPRING	4PB4025-1106P1
80	BASE FRAME	2PP4053-1969G1

ZEICHNUNG 3 - PRINTER UNIT (3/4)


LISTE 3 - PRINTER UNIT (3/4)



NR.	BEZEICHNUNG	BESTELL-NR.
2	PLATEN ASSY	4PA4053-2270G1
2A	PLATEN GEAR A	3PP4025-2815P1
3	LFPULSE MOTOR	3PB4053-1982P1
3A	DRIVE GEAR	3PB4055-1077P1
7	SHPT PCB (SENSOR BOARD)	4YA4053-2289G1
14	CONNECTOR CORD	4YS4011-4366P1
25	PLATEN GEAR ASSY	4PA4053-1972G1
26	FEED ROLLER SHAFT	3PB4053-1973P1
27	STACKER SHAFT	3PP4053-1974G1
28	LFBUSHING	4PP4053-1330P1
29	LFKNOB GEAR	4PP4053-1321P1
30	LFGEAR	4PP4053-1331P1
31	STACKER GEAR L	4PP4044-2813P1
32	CHANGE GEAR	4PP4053-1981P1
33	IDLE GEAR A	4PP4053-1980P1
34	IDLE GEAR B	4PP4053-2197P1
35	SENSOR ARM A	4PP4053-2271P1
36	SENSOR ARM B	4PP4053-2154P1
37	SPRING PIN	SPP1.6-12-SUS
69	POLYURETHANE FOAM	LM-7261-67
70	FRICTION SPRING	4PP4053-2336G1
71	EPICYCLIC BRACKET	4PP4053-2195G1
72	FEED ROLLER SPRING B	4PP4053-1983P1
73	FEED ROLLER SPRING A	4PP4053-1976P1
74	PLATEN COLLAR	4PP4053-1971P1
75	FEED ROLLER SPRING C	4PP4053-2023P1
76	GUARD	4PB4053-2296P1
77	CHANGE ARM A	4PP4053-1977P1
77A	CHANGE BRACKET TIGHT	4PP4053-2194G1
80	BASE FRAME	2PP4053-1969G1

ZEICHNUNG 4 - PRINTER UNIT (4/4)

LISTE 4 - PRINTER UNIT (4/4)



NR.	BEZEICHNUNG	BESTELL-NR.
44	HEADCABLE	2PU4007-1170P1
45	RIBBON FEED GEAR ASSY	4PA4025-2832G3
46	CONNECTOR(HEADCONNECT)	3PB4025-1241P1
47	GUIDE ROLLER	4PP4053-1315P1
48	SPACE MOTOR ASSY	4YX4053-1356G2
49	HEADCLAMP	4PP4025-1048P1
50	CARRIAGE FRAME ASSY	4PP4053-2000G1
51	CONTACT PRESSURE	4PP4025-2960P1
78	GUIDE ROLLER PLATE	4PP4053-1361P1